

1023E, 1025R and 1026R Compact Utility Tractors



JOHN DEERE

TECHNICAL MANUAL

**1023E, 1025R, and 1026R Compact
Utility Tractors (S.N. HJ100001—)**

TM149119 31JUL23 (ENGLISH)


John Deere Augusta Works
PRINTED IN U.S.A.

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC -19-20SEP22-1/1

Preview Only

Contents

Section 10—General Information

- Group 05A—Safety
- Group 05B—General References
- Group 05C—Technical Specific References
- Group 05D—Fuel and Lubricants
- Group 05E—Serial Number Locations

Section 20—Engine Repair

- Group 05—Engine
- Group 10—Cooling System

Section 30—Fuel, Air Intake, and Exhaust Repair

- Group 05—Fuel
- Group 10—Air Intake
- Group 15—Exhaust

Section 40—Electrical Repair

- Group 05—Electrical Connector Repair
- Group 10—Battery, Starter, and Alternator
- Group 15—Electrical System Components

Section 50—Drive Systems and Transmission Repair

- Group 05—Power Train
- Group 10—Mechanical Front Wheel Drive
- Group 15—Differential
- Group 20—PTO

Section 60—Steering Repair

- Group 05—Steering

Section 61—Brake Repair

- Group 05—Brake

Section 70—Hydraulics Repair

- Group 05—Hydraulic Pump and Filter
- Group 10—Rockshaft
- Group 15—Range Control and Three Point Hitch
- Group 20—Selective Control Valve
- Group 25—Hydraulic Lines

Section 80—Miscellaneous Repair

- Group 05—Hood and Side Panels
- Group 15—Wheels
- Group 20—Mid-Mount Lift

Section 90—Cab/Open Operator's Station Repair

- Group 05—Seat and Support
- Group 10—Control Console
- Group 15—Roll-Gard
- Group 20—Cab Components
- Group 25—Open Operator Station Components

Section 211—Diagnostic Trouble Codes

- Group 05—General References
- Group 10—Diagnostic Display Messages

Section 212—Observable Symptoms and System Diagnostics

- Group 05—General References
- Group 20—Engine System Diagnostics
- Group 30—Fuel, Air Intake, Exhaust, and Cooling System Diagnostics
- Group 40—Electrical System Diagnostics
- Group 50—Drive Systems and Transmission System Diagnostics
- Group 60—Steering System Diagnostics
- Group 61—Brakes System Diagnostics
- Group 70—Hydraulic System Diagnostics

Section 220—Engine Operation, Test, and Adjustments

- Group 05—General References
- Group 10—Calibrations, Preliminary Checks and Operational Checks
- Group 20—Theory of Operation
- Group 40—Component and Connector Information
- Group 50—Tests and Adjustments

Section 230—Fuel, Air Intake, Exhaust, and Cooling Operation, Test, and Adjustments

- Group 05—General References
- Group 10—Calibrations, Preliminary Checks and Operational Checks
- Group 20—Theory of Operation
- Group 40—Component and Connector Information
- Group 50—Tests and Adjustments

Section 240A—Electrical General and Theory of Operation

- Group 05—General References

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2023
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2012, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022

Group 20—Electrical Theory of Operation

Section 240B—Electrical Schematics

Group 05—General References
 Group 30AA—Starting and Charging (SE1)
 Group 30BA—Lighting—Without License Light (SE2A)
 Group 30BB—Lighting—With License Light (SE2B)
 Group 30BC—Brake Switch, Horn, And Rear Trailer Connector (SE2C)
 Group 30CA—Instrument Cluster Control (ICC) (SE3)
 Group 30DA—Kits (SE4)
 Group 30EA—Mauser Cab (SE5)

Section 240C—Electrical Components and Connectors

Group 05—General References
 Group 40A—Electrical Assemblies, Modules, and Control Units
 Group 40B—Sensors
 Group 40E—Lights
 Group 40F—Fuses
 Group 40G—Charging
 Group 40H—Monitoring/Warning Devices
 Group 40K—Relays
 Group 40M—Motors
 Group 40S—Switches
 Group 40W—Wiring Harnesses
 Group 40X—Interconnects
 Group 40Y—Solenoids and Electrically Actuated Mechanical Devices
 Group 40Z—Ground Points

Section 240D—Electrical Tests and Adjustments

Group 05—General References
 Group 50—Tests and Adjustments

Section 250—Drive Systems and Transmission Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 260—Steering Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 261—Brakes Operation, Test, and Adjustments

Group 05—General References

Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 270—Hydraulics Operation, Test, and Adjustments

Group 05—General References
 Group 10—Calibrations, Preliminary Checks and Operational Checks
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information
 Group 50—Tests and Adjustments

Section 290—Cab/Open Operators Station Operation, Test, and Adjustments

Group 05—General References
 Group 20—Theory of Operation
 Group 30—Schematics
 Group 40—Component and Connector Information

Section 299—Service Tools

Group 05A—General References
 Group 05C—Dealer Fabricated and Service Tools

Section 10 General Information

Contents

| Page | Page |
|--|---|
| Group 05A—Safety | |
| Work In Ventilated Area..... | 10-05A-1 |
| Recognize Safety Information | 10-05A-1 |
| Avoid Backover Accidents..... | 10-05A-1 |
| Prevent Machine Runaway..... | 10-05A-2 |
| Avoid Contact with Agricultural Chemicals..... | 10-05A-2 |
| Clean Vehicle of Hazardous Pesticides | 10-05A-2 |
| Use a Safety Chain..... | 10-05A-3 |
| Work in Clean Area | 10-05A-3 |
| Decommissioning — Proper Recycling and Disposal of Fluids and Components | 10-05A-4 |
| Avoid Harmful Asbestos Dust..... | 10-05A-4 |
| Avoid Hot Exhaust..... | 10-05A-5 |
| Clean Exhaust Filter Safely | 10-05A-6 |
| Handle Fuel Safely—Avoid Fires..... | 10-05A-7 |
| Prepare for Emergencies..... | 10-05A-7 |
| Handle Fluids Safely—Avoid Fires..... | 10-05A-7 |
| Avoid High-Pressure Fluids | 10-05A-8 |
| Install All Guards | 10-05A-8 |
| Use Proper Lifting Equipment..... | 10-05A-8 |
| Illuminate Work Area Safely | 10-05A-9 |
| Live With Safety..... | 10-05A-9 |
| Service Machines Safely | 10-05A-9 |
| Support Machine Properly | 10-05A-10 |
| Remove Paint Before Welding or Heating | 10-05A-10 |
| Park Machine Safely..... | 10-05A-10 |
| Stay Clear of Rotating Drivelines..... | 10-05A-11 |
| Follow Safety Instructions..... | 10-05A-11 |
| Use Proper Tools | 10-05A-12 |
| Service Tires Safely..... | 10-05A-12 |
| Keep ROPS Installed Properly | 10-05A-13 |
| Construct Dealer-Made Tools Safely..... | 10-05A-13 |
| Practice Safe Maintenance..... | 10-05A-14 |
| Understand Signal Words..... | 10-05A-14 |
| Replace Safety Signs | 10-05A-15 |
| Avoid Heating Near Pressurized Fluid Lines | 10-05A-15 |
| Wear Protective Clothing..... | 10-05A-15 |
| Service Accumulator Systems Safely..... | 10-05A-16 |
| Handling Batteries Safely | 10-05A-17 |
| Handle Agricultural Chemicals Safely..... | 10-05A-18 |
| Service Cooling System Safely | 10-05A-18 |
| Use Steps and Handholds Correctly | 10-05A-19 |
| Transport Tractor Safely | 10-05A-19 |
| | Group 05B—General References |
| | Deliver Safely |
| | Information Available in Sections, Groups and Subgroups |
| | Glossary of Terms..... |
| | Trademarks |
| | Group 05C—Technical Specific References |
| | Unified Inch Bolt and Screw Torque Values..... |
| | Metric Bolt and Screw Torque Values..... |
| | Metric Cap Screw Torque Values—Grade 7 |
| | Gasket Sealant Application |
| | Service Recommendations for O-Ring Boss Fittings..... |
| | Service Recommendations for Flat Face O-Ring Seal Fittings |
| | Group 05D—Fuel and Lubricants |
| | Diesel Fuel..... |
| | Handling and Storing Diesel Fuel |
| | Engine Oil |
| | Alternative and Synthetic Lubricants |
| | Lubricant Storage |
| | Mixing of Lubricants..... |
| | Grease..... |
| | Transmission and Hydraulic Oil..... |
| | Diesel Engine Coolant..... |
| | Group 05E—Serial Number Locations |
| | Serial Numbers..... |
| | Machine Product Identification Number |
| | Engine Serial Number |
| | Transmission Serial Number |
| | CAB Serial Number |