



9410, 9510 and 9610 Combines Diagnosis and Tests

TECHNICAL MANUAL

9410, 9510 and 9610 Combines Diagnosis and Tests

TM1702 (29AUG97) English

Preview Only

For complete service information also see:

Cutting Platforms, Corn Heads and Row Crop Heads	TM1581
GreenStar™ Yield Mapping Repair, Operation and Test	TM1685
GreenStar™ Yield Monitoring Repair, Operation and Test	TM1686
9410, 9510, and 9610 Combines Repair	TM1701
Cam Lobe Motors	CTM19
Engine Accessories	CTM67
Electronic Fuel Injection	CTM68
Alternators and Starting Motors	CTM77
6081 Diesel Engines	CTM86
6068 Engine	CTM104

John Deere Harvester Works
TM1702 (29AUG97)

LITHO IN U.S.A.
ENGLISH



Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC -19-22MAY92-1/1

Contents

SECTION 210—General

- Group 05—Safety
- Group 10—Combine or Component Identification
- Group 15—General Specifications
- Group 20—Diagnostic/Testing Procedures
- Group 25—Electrical System Operational Checkout

SECTION 220—Engine Operation and Tests

- Group 10—Cooling System and Rotary Screen Operation
- Group 15—6068 Engine Operation
- Group 20—6081 Engine Operation—Bosch

SECTION 230—Fuel/Air Operation and Tests

- Group 05—Air Intake System
- Group 10—Fuel System

SECTION 240—Electrical System Operation and Tests

- Group 5A—Electrical Schematic Symbols
- Group 5B—How to Use This Diagnostic Information
- Group 5C—Service Equipment and Tools
- Group 5D—Seven Step Electrical Test Procedure
- Group 5E—Visually Inspect Electrical System
- Group 5F—Wiring Diagram and Schematic Information
- Group 10—Ground Points
- Group 15A—Air Suspension Seat Diagnostics
- Group 15B—Alternator and Battery Diagnostics
- Group 15C—Auxiliary Field Lights Diagnostics
- Group 15D—Auxiliary Power Outlet Diagnostics
- Group 15E—Backshaft Speed Adjust Diagnostics
- Group 15F—Combine Data Center Diagnostics
- Group 15G—Concave Position Adjust Diagnostics
- Group 15H—Contour Master™ (HDR Tilt) Control System Identification
- Group 15I—Contour Master™ (HDR Tilt) Control Diagnostics—Type A
- Group 15J—Contour Master™ (HDR Tilt) Control Diagnostics—Type B
- Group 15K—Corn Head Adjustable Deck Plates Diagnostics
- Group 15L—Corner Post Gauges Diagnostics
- Group 15M—Cylinder Speed Adjust Diagnostics
- Group 15N—DIAL-A-MATIC™ System Identification

- Group 15O—DIAL-A-MATIC™ Diagnostics—Type A
- Group 15P—DIAL-A-MATIC™ Diagnostics—Type B
- Group 15Q—DIAL-A-SPEED™ Diagnostics
- Group 15R—Dual Display Digital Tachometer Diagnostics
- Group 15S—Electric Fuel Pump Diagnostics
- Group 15T—Engine Compartment Relay Panel Diagnostics
- Group 15U—Engine Oil Pressure Monitor Diagnostics
- Group 15V—Fan Speed Adjust Diagnostics
- Group 15W—Four-Wheel Drive Diagnostics
- Group 15X—HarvesTrak™ Diagnostics
- Group 15Y—Header Engage Diagnostics
- Group 15Z—Header Raise/Lower Diagnostics
- Group 15AA—Header Raise/Lower Diagnostics With DIAL-A-MATIC™
- Group 15AB—Heating and Air Conditioning Diagnostics
- Group 15AC—Horn Diagnostics
- Group 15AD—Injection Pump (Engine Control) System Identification
- Group 15AE—Injection Pump System—6081 John Deere Type A—Diagnostics
- Group 15AF—Injection Pump System—6081 John Deere Type B—Diagnostics
- Group 15AG—Injection Pump System—6068 Engine—Diagnostics
- Group 15AH—Lighting System Diagnostics
- Group 15AI—Low Shaft Speed Monitor Diagnostics (w/o GreenStar™)
- Group 15AJ—Low Shaft Speed Monitor Diagnostics (with GreenStar™)
- Group 15AK—Parking Brake Diagnostics
- Group 15AL—Power Distribution Board Diagnostics
- Group 15AM—Radio System Diagnostics
- Group 15AN—Reel/Belt Speed Diagnostics
- Group 15AO—Reel Fore/Aft Diagnostics
- Group 15AP—Reel Raise/Lower Diagnostics
- Group 15AQ—Separator Engage Diagnostics
- Group 15AR—Shoe Lighting Diagnostics
- Group 15AS—Starting Aid Diagnostics
- Group 15AT—Starting System Diagnostics

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 1997
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual

210	Group 15AU—Unloading Auger Engage Diagnostics
	Group 15AV—Unloading Auger Swing System Identification
	Group 15AW—Unloading Auger Swing Diagnostics—Type A
220	Group 15AX—Unloading Auger Swing Diagnostics—Type B
	Group 15AY—Warning Display Panel Diagnostics
	Group 15AZ—Wiper System Diagnostics
	Group 20A—Circuit Code Listing
230	Group 20B—Connector Number Listing and End Views

SECTION 250—Power Train Operation and Tests

	Group 00—Power Train Diagnostic Specifications
	Group 05—Transmission and Final Drives
240	Group 10—Hydrostatic Drive System Adjustments
	Group 15—Hydrostatic Drive System Operational Tests
	Group 20—Hydraulic/Hydrostatic System Overheating Diagnostics
250	Group 25—Hydro Charge Pressure Low Diagnostics
	Group 30—Hydrostatic Drive System Diagnostics
	Group 32—Transmission Lubrication Pump Diagnostics
255	Group 35—Hydrostatic Drive System Theory of Operation

SECTION 255—Four-Wheel Drive

	Group 00—Four-Wheel Drive
	Group 05—Four-Wheel Drive System Operational Checks
260	Group 10—Four-Wheel Drive Diagnostics
	Group 15—Four-Wheel Drive System Theory of Operation

SECTION 260—Service Brakes System Operation and Tests

270	Group 00—Service Brake System Specifications and Adjustments
	Group 05—Service Brake System Diagnostics
	Group 10—Service Brake System Theory of Operation
275	Group 15—Mechanical Park Brake Specifications and Adjustments
	Group 20—Mechanical Park Brake Diagnostics
	Group 25—Mechanical Park Brake Theory of Operation

SECTION 270—Hydraulic Operation and Tests

280	Group 05—Hydraulic System Diagnostics
	Group 10—Hydraulic System Diagnostic Specifications
	Group 10A—Hydraulic System Operational Tests and Adjustments

	Group 15A—Backshaft Speed Diagnostics
	Group 15B—Chaff Spreader Diagnostics
	Group 15C—Corn Head Deck Plates Adjust Diagnostics
	Group 15D—Cylinder Speed Adjust Diagnostics
	Group 15E—Header Raise/Lower Diagnostics
	Group 15F—Header Tilt (Contour Master) Diagnostics
	Group 15G—Overheating Diagnostics
	Group 15H—Overall Diagnostics—Hydraulic System
	Group 15I—Reel Belt/Speed Diagnostics
	Group 15J—Reel Fore/Aft Diagnostics
	Group 15K—Reel Raise/Lower Diagnostics
	Group 15L—Unloading Auger Swing Diagnostics
	Group 20A—Backshaft Speed Theory of Operation
	Group 20B—Chaff Spreader—Theory of Operation
	Group 20C—Corn Head Deck Plates Adjust Theory of Operation
	Group 20D—Cylinder Speed Adjust Theory of Operation
	Group 20E—Header Raise/Lower Theory of Operation
	Group 20F—Header Tilt (Contour Master) Theory of Operation
	Group 20G—Overheating Theory of Operation
	Group 20H—Overall Hydraulic System Theory of Operation
	Group 20I—Reel/Belt Speed Theory of Operation
	Group 20J—Reel Fore/Aft Theory of Operation
	Group 20K—Reel Raise/Lower Theory of Operation
	Group 20L—Unloading Auger Swing Theory of Operation

SECTION 275—Main Engine Gearcase Systems Operation and Test

	Group 00—Engine Gearcase Systems Diagnostics
	Group 05—Main Engine Gearcase Hydraulic Specifications
	Group 10—Steering System Specifications and Adjustments
	Group 15—Steering System Diagnostics
	Group 20—Steering System Theory of Operation
	Group 25—Separator Drive System Diagnostics
	Group 30—Separator Drive System Theory of Operation
	Group 35—Separator Drive Pressure Low Diagnostics
	Group 40—Separator Drive Temp High Diagnostics
	Group 45—Separator Drive Filter Restricted Diagnostics
	Group 50—Engine Gearcase Hydraulic Theory of Operation
	Group 55—Engine Gearcase Control Valve Theory

Continued on next page

- of Operation
- Group 60—Unloading Auger Engage System
Diagnostics
- Group 65—Unloading Auger Engage System
Theory of Operation

SECTION 280—DIAL-A-MATIC System Operation and Tests

- Group 00—DIAL-A-MATIC Adjustments
- Group 05—DIAL-A-MATIC System Identification
- Group 10—DIAL-A-MATIC System—Type A
Diagnostics
- Group 15—DIAL-A-MATIC System—Type B
Diagnostics
- Group 20—DIAL-A-MATIC System Header
Mechanical Diagnostics
- Group 25—DIAL-A-MATIC System—Type A Theory
of Operation

SECTION 290—Heating/Air Conditioning Operation and Tests

- Group 05—Specifications and Special Tools
- Group 10—Heating/Air Conditioning System
Diagnostic Information
- Group 15—Heating/Air Conditioning System—
Diagnostics
- Group 20—Heating/Air Conditioning—Theory of
Operation

Preview Only