

**Z225, Z245 EZtrak Mower
(S.N. 100001-)
Z235, Z255 EZtrak Mower
(S.N. 130001-)**



TECHNICAL MANUAL

**Z225, Z245 (S.N. 100001-)
Z235, Z255 (S.N. 130001-)
EZtrak™ Mower**

TM112919 11JAN16 (ENGLISH)

John Deere Power Products
PRINTED IN U.S.A.




Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-15APR14-1/1

Preview Only

Contents

Section 10—General Information

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Fuel and Lubricants
- Group 20—Machine Specifications

Section 20—Single Cylinder Engine Repair

- Group 10—Engine Single Cylinder

Section 30—V-Twin Engine Repair

- Group 10—Repair Engine V-Twin

Section 40—Electrical Repair

- Group 10—Component Location
- Group 20—Wiring Harness

Section 50—Power Train Repair

- Group 10—Component Location
- Group 20—Repair

Section 60—Attachments Repair

- Group 10—Component Location
- Group 20—Repair

Section 70—Miscellaneous Repair

- Group 10—Component Location
- Group 20—Repair

Section 220—Single Cylinder Diagnosis, Tests, and Adjustments

- Group 10—Diagnosis
- Group 20—Tests and Adjustments

Section 230—V-Twin Engine Diagnosis, Tests, and Adjustments

- Group 10—Diagnosis
- Group 20—Tests and Adjustments

Section 240—Electrical Diagnosis, Tests, and Adjustments

- Group 10—Theory of Operation
- Group 20—Diagnosis
- Group 30—Tests and Adjustments
- Group 40—Wiring Schematics
- Group 50—Connector Information

Section 250—Power Train Diagnosis, Tests, and Adjustments

- Group 20—Theory of Operation
- Group 30—Diagnosis
- Group 40—Tests and Adjustments

Section 260—Attachments Diagnosis, Tests, and Adjustments

- Group 20—Diagnosis
- Group 30—Tests and Adjustments

Section 299—Service Tools and Kits

- Group 10—Service Tools

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2016
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2012, 2013, 2014, 2015

Preview Only

Section 10 General Information

Contents

	Page		Page
Group 05—Safety			
Recognize Safety Information	10-05-1	Lubricant Storage	10-15-3
Understand Signal Words.....	10-05-1	Gasoline and Engine Storage.....	10-15-4
Follow Safety Instructions.....	10-05-1	Carburetor Cleaning	10-15-5
Practice Safe Maintenance.....	10-05-2	Carburetor Cleaning Methods	10-15-6
Use Proper Tools	10-05-2		
Handle Fluids Safely—Avoid		Group 20—Machine Specifications	
Fires.....	10-05-3	Machine Specifications Z225 and	
Drain Gasoline When Storing		Z245 (S.N. -130000).....	10-20-1
Machine	10-05-3	Machine Specifications Z235 and	
Prevent Acid Burns.....	10-05-4	Z255 (S.N. 130001-).....	10-20-2
Prevent Battery Explosions	10-05-4	Product Identification Number	
Handling Batteries Safely	10-05-5	Location (S.N. -130000)	10-20-3
Prepare for Emergencies.....	10-05-5	Product Identification Number	
Park Machine Safely.....	10-05-6	Location (S.N. 130001-)	10-20-3
Support Machine Properly	10-05-6		
Wear Protective Clothing.....	10-05-6		
Work in Clean Area	10-05-7		
Service Machines Safely	10-05-7		
Work In Ventilated Area.....	10-05-7		
Illuminate Work Area Safely	10-05-8		
Replace Safety Signs	10-05-8		
Use Proper Lifting Equipment.....	10-05-8		
Follow Tire Recommendations	10-05-9		
Decommissioning: Proper			
Recycling and Disposal of Fluids			
and Components	10-05-9		
Protect Against High Pressure			
Spray	10-05-10		
Live With Safety.....	10-05-10		
Group 10—General Specifications			
Service Recommendations for			
O-Ring Boss Fittings.....	10-10-1		
Service Recommendations For			
Flat Face O-Ring Seal Fittings	10-10-2		
Metric Cap Screw Torque			
Values—Grade 7	10-10-2		
Metric Bolt and Screw Torque			
Values.....	10-10-3		
Unified Inch Bolt and Screw Torque			
Values.....	10-10-4		
Group 15—Fuel and Lubricants			
Summary of References.....	10-15-1		
Gasoline Engine Oil.....	10-15-1		
Oil Filters	10-15-1		
Gasoline Fuel for 4-Cycle			
Engines.....	10-15-2		
Transaxle Oil	10-15-2		
Grease.....	10-15-2		
Mixing of Lubricants.....	10-15-3		
Alternative and Synthetic			
Lubricants	10-15-3		