

# **Select Series Tractors X330, X350, X354, X370, X380, X384, X390, X394 (S.N. 10001-)**



## **TECHNICAL MANUAL**

**Select Series™ Tractors  
X330, X350, X354, X370, X380,  
X384, X390, X394 (S.N. 010001-)**

**TM138119 07DEC18 (ENGLISH)**

Preview Only

**John Deere Horicon Works**  
PRINTED IN U.S.A.



# Introduction

## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC -19-15APR14-1/1

Preview Only

# Contents

## Section 10—General Information

- Group 10—Safety
- Group 20—General Specifications
- Group 30—O-Ring Seal Service Recommendations
- Group 40—Fuels and Lubricants
- Group 50—Machine Specifications

## Section 20—Engine Repair

- Group 10—Engine 44J677
- Group 20—Engine FS600V
- Group 30—Engine FS651V

## Section 30—Electrical Repair

- Group 10—Wiring Harness

## Section 40—Power Train Repair

- Group 10—Power Train

## Section 50—Steering and Brake Repair

- Group 10—Steering
- Group 20—Brakes

## Section 60—Hydraulic Repair

- Group 10—Hydraulics

## Section 70—Attachment Repair

- Group 10—Attachments

## Section 80—Operator's Station Repair

- Group 10—Operator's Station

## Section 90—Miscellaneous Repair

- Group 10—Miscellaneous

## Section 220—Engine Operation, Tests, and Adjustments

- Group 10—Component Location
- Group 20—Theory of Operation
- Group 30—Diagnosis
- Group 40—Tests and Adjustments 44J677
- Group 50—Tests and Adjustments FS600V
- Group 60—Tests and Adjustments FS651V

## Section 230—Electrical Operation, Tests, and Adjustments

- Group 05—General Information
- Group 10—Component Location
- Group 20—Theory of Operation (S.N. -070000)

- Group 25—Theory of Operation (S.N. 070001-)
- Group 30—Schematics
- Group 40—Diagnosis
- Group 50—Tests and Adjustments
- Group 60—Connectors
- Group 70—DTCs, ICC
- Group 80—Electronic Control Units

## Section 240—Power Train Operation, Tests, and Adjustments

- Group 10—Component Location
- Group 20—Theory of Operation
- Group 30—Diagnosis
- Group 40—Tests and Adjustments

## Section 250—Steering and Brake Operation, Tests, and Adjustments

- Group 10—Component Location
- Group 20—Theory of Operation
- Group 30—Diagnosis
- Group 40—Tests and Adjustments

## Section 260—Hydraulic System Operation, Tests, and Adjustments

- Group 10—Component Location
- Group 20—Theory of Operation
- Group 30—Schematics
- Group 40—Diagnosis
- Group 50—Tests and Adjustments

## Section 270—Attachment Operation, Tests, and Adjustments

- Group 10—Component Location
- Group 20—Diagnosis
- Group 30—Tests and Adjustments

## Section 280—Miscellaneous Operation, Tests, and Adjustments

- Group 10—Tests and Adjustments

## Section 299—Service Tools and Kits

- Group 10—Service Tools

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2019  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved.  
A John Deere ILLUSTRATION™ Manual  
Previous Editions  
Copyright © 2018, 2017, 2016

Preview Only

## Section 10 General Information

### Contents

	Page		Page
<b>Group 10—Safety</b>			
Recognize Safety Information .....	10-10-1	Engine Break-In Oil .....	10-40-3
Understand Signal Words .....	10-10-1	Alternative Lubricants .....	10-40-3
Replace Safety Signs .....	10-10-1	Synthetic Lubricants .....	10-40-3
Handle Fluids Safely—Avoid		Lubricant Storage .....	10-40-4
Fires .....	10-10-2	Mixing of Lubricants .....	10-40-4
Prepare for Emergencies .....	10-10-2	Grease .....	10-40-4
Prevent Battery Explosions .....	10-10-2	Mower Spindle Grease .....	10-40-4
Prevent Acid Burns .....	10-10-3	Transaxle Oil .....	10-40-5
Wear Protective Clothing .....	10-10-3		
Avoid High-Pressure Fluids .....	10-10-4	<b>Group 50—Machine Specifications</b>	
Avoid Heating Near Pressurized		Record Identification Numbers .....	10-50-1
Fluid Lines .....	10-10-4	Machine Specifications .....	10-50-2
Service Machines Safely .....	10-10-4		
Use Proper Tools .....	10-10-5		
Park Machine Safely .....	10-10-5		
Support Machine Properly .....	10-10-5		
Use Proper Lifting Equipment .....	10-10-6		
Work in Clean Area .....	10-10-6		
Protect Against High Pressure			
Spray .....	10-10-6		
Illuminate Work Area Safely .....	10-10-7		
Work In Ventilated Area .....	10-10-7		
Remove Paint Before Welding or			
Heating .....	10-10-7		
Avoid Harmful Asbestos Dust .....	10-10-8		
Follow Tire Recommendations .....	10-10-8		
Dispose of Waste Properly .....	10-10-8		
Handle Chemical Products Safely .....	10-10-9		
Live With Safety .....	10-10-9		
<b>Group 20—General Specifications</b>			
Metric Bolt and Screw Torque			
Values .....	10-20-1		
Metric Cap Screw Torque			
Values—Grade 7 .....	10-20-1		
Unified Inch Bolt and Screw Torque			
Values .....	10-20-2		
Gasket Sealant Application .....	10-20-3		
<b>Group 30—O-Ring Seal Service Recommendations</b>			
Face Seal Fittings With Inch Stud			
Ends Torque .....	10-30-1		
Face Seal Fittings With Metric Stud			
Ends Torque .....	10-30-2		
Service Recommendations for Fittings			
Flat Face O-Ring Seal .....	10-30-3		
Service Recommendations for			
O-Ring Boss Fittings .....	10-30-3		
<b>Group 40—Fuels and Lubricants</b>			
Gasoline .....	10-40-1		
Gasoline Storage .....	10-40-2		
Engine Oil .....	10-40-2		