

Individual Nozzle Control Diagnostic Technical Manual



JOHN DEERE

DIAGNOSTIC TECHNICAL MANUAL

Individual Nozzle Control

TM173119 20NOV24 (ENGLISH)

John Deere Precision Upgrades
PRINTED IN U.S.A.

Introduction

Foreword

The diagnostic technical manual is written for an experienced technician. Essential tools required to perform certain type of work are identified in Section 300, and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text.



This is the safety-alert symbol. When the symbol is shown on the equipment or in a manual, be alert to the potential for personal injury.

Diagnostic technical manuals are comprised of general information, checks, theory of operation, schematic and

diagnostic procedures. Sections in a diagnostic technical manual help quickly identify the likely cause of routine failures. Component sections include images of the component or connector and location on the equipment.

The diagnostic technical manual references component manuals and repair technical manuals. Repair technical manuals are organized for various components requiring service instruction.

Both diagnostic and repair technical manuals are concise guides for specific equipment. They are on-the-job instructions containing vital information to diagnose, analyze, test, and repair the equipment.

JY20514,00008DB -19-28NOV11-1/1

Preview Only

Contents

Section 210—General Information

- Group 05A—Safety
- Group 05B—References for Technical Information
- Group 10—General References
- Group 50—Diagnostic Philosophy

Section 211—Diagnostic Trouble Codes

- Group 05—General Information
- Group MNA—Master Nozzle Control Unit Software
 - Diagnostic Trouble Codes (MNA)

Section 212—Observable Symptom and System Diagnostics

- Group 40A—Electrical: Nozzle Symptoms
- Group 40B—Electrical: Key FOB Symptoms
- Group 45—Electronic Control Units

Section 240—Electrical

- Group 05A—General Information
- Group 05B—Configuration Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 30—Schematic
- Group 50—Diagnostic Tests and Adjustments

Section 245—Electronic Control Units

- Group 05—General Information
- Group 10—Programming Electronic Control Units
- Group 20—Theory of Operation
- Group 30—Schematic
- Group 50—Diagnostic Tests and Adjustments
- Group MNA—Master Nozzle Control Unit (MNC)
 - Diagnostic Addresses

Section 249—Electrical Component Information

- Group 05—General Information
- Group 40A—Component Information

Section 300—Tools

- Group 05—Service Tools and Kits

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.
The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2022
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual

Preview Only

Section 210 General Information

Contents

Page	Page
Group 05A—Safety	
Recognize Safety Information	210-05A-1
Understand Signal Words	210-05A-1
Prevent Machine Runaway	210-05A-1
Handle Fluids Safely—Avoid Fires	210-05A-2
Prevent Battery Explosions	210-05A-2
Prepare for Emergencies	210-05A-2
Handling Batteries Safely	210-05A-3
Handle Agricultural Chemicals Safely	210-05A-4
Park Machine Safely	210-05A-4
Support Machine Properly	210-05A-5
Wear Protective Clothing	210-05A-5
Work in Clean Area	210-05A-5
Clean Vehicle of Hazardous Pesticides	210-05A-6
Service Machines Safely	210-05A-6
Work In Ventilated Area	210-05A-6
Illuminate Work Area Safely	210-05A-7
Replace Safety Signs	210-05A-7
Use Proper Lifting Equipment	210-05A-7
Wait Before Opening High-Pressure Fuel System	210-05A-8
Service Accumulator Systems Safely	210-05A-8
Avoid High-Pressure Fluids	210-05A-8
Use Steps and Handholds Correctly	210-05A-9
Remove Paint Before Welding or Heating	210-05A-9
Avoid Heating Near Pressurized Fluid Lines	210-05A-9
Keep ROPS Installed Properly	210-05A-10
Service Tires Safely	210-05A-10
Avoid Harmful Asbestos Dust	210-05A-10
Practice Safe Maintenance	210-05A-11
Use Proper Tools	210-05A-11
Decommissioning — Proper Recycling and Disposal of Fluids and Components	210-05A-12
Live With Safety	210-05A-12
Group 05B—References for Technical Information	
Metric Bolt and Screw Torque Values	210-05B-1
Unified Inch Bolt and Screw Torque Values	210-05B-2
Face Seal Fittings Assembly and Installation—All Pressure Applications	210-05B-3
Metric Face Seal and O-Ring Stud End Fitting Torque Chart—Standard Pressures	210-05B-4
Metric Face Seal and O-Ring Stud End Fitting Torque Chart—High Pressure Applications	210-05B-5
SAE Face Seal and O-Ring Stud End Fitting Torque Chart—Standard Pressures	210-05B-6
SAE Face Seal and O-Ring Stud End Fitting Torque Chart—High Pressure Applications	210-05B-7
Four Bolt Flange Fittings Assembly and Installation—All Pressure Applications	210-05B-8
SAE Four Bolt Flange Cap Screw Torque Values—Standard Pressure Applications	210-05B-8
SAE Four Bolt Flange Cap Screw Torque Values—High Pressure Applications	210-05B-9
External Hexagon Port Plug Torque Chart	210-05B-10
Group 10—General References	
Information Available in Sections, Groups, and Subgroups	210-10-1
Trademarks	210-10-1
Regions and Countries	210-10-2
Group 50—Diagnostic Philosophy	
Basic Diagnostic Philosophy	210-50-1