

**Select Series Tractors  
X330, X350, X354, X370,  
X380, X384, X390, X394  
Serial Number 150001-**

**TECHNICAL MANUAL**

**Select Series™ Tractors  
X330, X350, X354, X370, X380,  
,X384, X390, X394**


**TM175819 15SEP22 (ENGLISH)**

# Introduction

## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-20SEP22-1/1

Preview Only

# Contents

## Section 10—General Information

- Group 10—Safety
- Group 20—General Specifications
- Group 30—O-Ring Seal Service Recommendations
- Group 40—Fuels and Lubricants
- Group 50—Machine Specifications

## Section 20—Engine Repair — Common

- Group 05—General Information

## Section 20A—Engine Repair - X330

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

## Section 20B—Engine Repair - X350, X354, X370

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

## Section 20C—Engine Repair - X380, X384, X390, and X394

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

## Section 40—Electrical Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

## Section 50—Drivetrain Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble

## Section 60—Steering and Brake Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble

## Section 70—Hydraulic Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble

## Section 80—Attachment and Machine-Specific Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble

## Section 90—Operator Station Repair

- Group 05—General Information
- Group 10—Remove and Install

## Section 210—General Information - Diagnostics

- Group 05—General Information

## Section 211—Diagnostic Trouble Codes

- Group 01—Control Unit ICC

## Section 212—System Diagnostics Access

- Group 220—Engine System Diagnostics
- Group 240—Electrical System Diagnostics
- Group 245—Electrical Control Unit Diagnostics
- Group 250—Drivetrain System Diagnostics
- Group 260—Steering and Brake System Diagnostics
- Group 270—Hydraulic System Diagnostics
- Group 280—Attachments and Machine-Specific System Diagnostics

## Section 220A—Engine System Diagnostics - X330

- Group 05—General Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

## Section 220B—Engine System Diagnostics - X350, X354, X370

- Group 05—General Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

Continued on next page

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2022  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved.  
A John Deere ILLUSTRATION™ Manual  
Previous Editions  
Copyright © 2018, 2017, 2016, 2019, 2020, 2021

**Section 220C—Engine System Diagnostics  
- X380, X384, X390, X394**

- Group 05—General Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

**Section 240—Electrical System Diagnostics**

- Group 05—General Information
- Group 20—Theory of Operation
- Group 30—Schematics
- Group 50A—Diagnostics
- Group 50—Test and Adjustments

**Section 245—Electrical Control Unit  
Diagnostics**

- Group 05—General Information
- Group 20—Theory of Operation
- Group 50A—Diagnostics

**Section 249—Electrical Connectors**

- Group 05—General Information
- Group 40A—Electrical Assembly Connectors
- Group 40B—Sensor Connectors
- Group 40E—Light Connectors
- Group 40F—Fuse Connectors
- Group 40S—Switch Connectors
- Group 40W—Terminals
- Group 40Y—Solenoid Connectors

**Section 250—Drivetrain Diagnostics**

- Group 05—General Information
- Group 20—Theory of Operation
- Group 50—Test and Adjustments
- Group 50A—Diagnostics

**Section 259—Drivetrain Systems -  
Component Information**

- Group 05—General Information
- Group 40—Components

**Section 260—Steering and Brake System  
Diagnostics**

- Group 05—General Information
- Group 20—Theory of Operation
- Group 50—Test and Adjustments
- Group 50A—Diagnostics

**Section 269—Steering and Brake Systems  
- Component Information**

- Group 05—General Information
- Group 40—Components

**Section 270—Hydraulic System Diagnostics**

- Group 05—General Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 30—Schematics

- Group 50—Test and Adjustments
- Group 50A—Diagnostics

**Section 279—Hydraulic Systems -  
Component Information**

- Group 05—General Information
- Group 40—Components

**Section 280—Attachment and Machine-  
Specific Diagnostics**

- Group 05—General Information
- Group 50—Test and Adjustments
- Group 50A—Diagnostics

**Section 289—Attachment and Machine-  
Specific Systems - Component  
Information**

- Group 05—General Information
- Group 40—Components

**Section 300—Tools, Equipment, and  
Other Material**

- Group 10—Service Tools

Preview Only

## Section 10 General Information

### Contents

	Page		Page
<b>Group 10—Safety</b>			
Live With Safety.....	10-10-1	Work in Clean Area .....	10-10-16
Follow Safety Instructions.....	10-10-1	Work In Ventilated Area.....	10-10-16
Avoid Harmful Asbestos Dust.....	10-10-1	<b>Group 20—General Specifications</b>	
Avoid Heating Near Pressurized		Metric Bolt and Screw Torque	
Fluid Lines .....	10-10-2	Values.....	10-20-1
Avoid High-Pressure Fluids .....	10-10-2	Metric Cap Screw Torque	
Avoid Hot Exhaust.....	10-10-2	Values—Grade 7 .....	10-20-2
Avoid Static Electricity Risk When		Unified Inch Bolt and Screw Torque	
Refueling .....	10-10-3	Values.....	10-20-3
Construct Dealer-Made Tools		Gasket Sealant Application .....	10-20-4
Safety.....	10-10-3	<b>Group 30—O-Ring Seal Service Recommendations</b>	
Decommissioning — Proper		Face Seal Fittings With Inch Stud	
Recycling and Disposal of Fluids		Ends Torque .....	10-30-1
and Components .....	10-10-4	Face Seal Fittings With Metric Stud	
Drain Gasoline When Storing		Ends Torque .....	10-30-2
Machine .....	10-10-4	Service Recommendations for Fittings	
Follow Tire Recommendations .....	10-10-5	Flat Face O-Ring Seal.....	10-30-3
Handle Agricultural Chemicals		Service Recommendations for	
Safety.....	10-10-5	O-Ring Boss Fittings.....	10-30-3
Handle Fluids Safely—Avoid		<b>Group 40—Fuels and Lubricants</b>	
Fires.....	10-10-6	Engine Break-In Oil .....	10-40-1
Illuminate Work Area Safely .....	10-10-6	Alternative Lubricants.....	10-40-1
Keep Electronic Control Unit		Synthetic Lubricants .....	10-40-1
Connectors Clean.....	10-10-6	Mixing of Lubricants.....	10-40-2
Keep ROPS Installed Properly .....	10-10-7	<b>Group 50—Machine Specifications</b>	
Park Machine Safely.....	10-10-7	Record Identification Numbers .....	10-50-1
Practice Safe Maintenance.....	10-10-8	Machine Specifications.....	10-50-2
Prepare for Emergencies.....	10-10-8		
Prevent Acid Burns.....	10-10-9		
Prevent Battery Explosions .....	10-10-9		
Prevent Machine Runaway.....	10-10-10		
Protect Against High Pressure			
Spray .....	10-10-10		
Recognize Safety Information .....	10-10-10		
Remove Paint Before Welding or			
Heating .....	10-10-11		
Service Accumulator Systems			
Safely.....	10-10-11		
Service and Operate Chemical			
Sprayers Safely .....	10-10-12		
Service Cooling System Safely .....	10-10-12		
Service Machines Safely .....	10-10-13		
Service Tires Safely.....	10-10-13		
Servicing Electronic Control Units.....	10-10-13		
Support Machine Properly .....	10-10-14		
Understand Signal Words.....	10-10-14		
Use Proper Lifting Equipment.....	10-10-14		
Use Proper Tools .....	10-10-15		
Wait Before Opening			
High-Pressure Fuel System.....	10-10-15		
Wear Protective Clothing.....	10-10-15		
Welding Near Electronic Control			
Units .....	10-10-16		