

G5^{Plus}[™] Universal Display and G5 Universal Display Technical Manual



JOHN DEERE

TECHNICAL MANUAL

G5Plus[™] Universal Display and G5 Universal Display Technical Manual


TM169219 06FEB25 (ENGLISH)

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX,TMIFC -19-20SEP22-1/1

Preview Only

Trademarks

Trademarks	
APEX™	Trademark of Deere & Company
AutoPath™	Trademark of Deere & Company
AutoTrac™	Trademark of Deere & Company
Bluetooth®	Trademark of Bluetooth SIG
CommandCenter™	Trademark of Deere & Company
CommandQuad™	Trademark of Deere & Company
e23™	Trademark of Deere & Company
Efficiency Manager™	Trademark of Deere & Company
Field Doc™	Trademark of Deere & Company
G5 ^{Plus} ™	Trademark of Deere & Company
GreenSeeker®	Trademark of Trimble Navigation Limited Corporation
GreenStar™	Trademark of Deere & Company
Hagie™	Trademark of Hagie Manufacturing Company
iGrade™	Trademark of Deere & Company
IMS™	Trademark of Deere & Company
iTEC™	Trademark of Deere & Company
IVT™	Trademark of Deere & Company
JDLink™	Trademark of Deere & Company
John Deere	Trademark of Deere & Company
John Deere Custom Performance™	Trademark of Deere & Company
Molex®	Registered Trademark of Molex, LLC
PowerShift™	Trademark of Deere & Company
RowSense™	Trademark of Deere & Company
SeedStar™	Trademark of Deere & Company
Service ADVISOR™	Trademark of Deere & Company
SERVICEGARD™	Trademark of Deere & Company
StarFire™	Trademark of Deere & Company
StellarSupport™	Trademark of Deere & Company
Wi-Fi®	Trademark of Wi-Fi Alliance

ch177nn,1662973019996 -19-07APR23-1/1

Preview Only

Contents

Section 210—General Information

Group 05A—Safety
Group 05B—General References
Group 05C—References for Technical Information
Group 20—G5 Universal Display Theory of Operation
Group 20A—AutoTrac Guidance Theory of Operation
Group 20B—AutoTrac Implement Guidance Theory of Operation
Group 20C—AutoTrac Turn Automation Theory of Operation
Group 20D—Autopath Theory of Operation
Group 20E—Equipment Manager Theory of Operation
Group 20F—Fields and Boundaries Theory of Operation
Group 20G—File Manager Theory of Operation
Group 20H—Flags Theory of Operation
Group 20J—ISOBUS Virtual Terminal and Virtual Implement Theory of Operation
Group 20K—iTEC Application Theory of Operation
Group 20L—Machine Sync Theory of Operation
Group 20M—Mapping Theory of Operation
Group 20N—Overlap Control Theory of Operation
Group 20O—Section Control Theory of Operation
Group 20P—Sharing Theory of Operation
Group 20Q—Software Manager Theory of Operation
Group 20R—System Tab Applications Theory of Operation
Group 20S—Work Monitor Theory of Operation
Group 20T—Work Setup Theory of Operation
Group 20U—Work Totals Theory of Operation
Group 100A—Factory Support Information

Section 211—Diagnostic Trouble Codes

Group NAV—DTCs (NAV)
Group VTi—Virtual Terminal Implement Software DTCs (VTi)
Group VTV—Virtual Terminal Vehicle Software DTCs (VTV)
Group ETH—Managed Ethernet Switch Software DTCs (ETH)

Section 212—Observable Symptom and System Diagnostics

Group 45—Electronic Control Units- Display Symptoms
Group 45A—Electronic Control Units- AutoTrac Symptoms
Group 45B—Electronic Control Units- AutoTrac Implement Guidance Symptoms
Group 45C—Electronic Control Units- AutoTrac Turn Automation Symptoms

Group 45D—Electronic Control Units - AutoPath Symptoms
Group 45E—Electronic Control Units- Equipment Manager
Group 45G—Electronic Control Units - File Manager
Group 45I—Electronic Control Units - ISOBUS Virtual Terminal and Virtual Implement
Group 45L—Electronic Control Units - Machine Sync
Group 45O—Electronic Control Units- Section Control
Group 45P—Electronic Control Units - Sharing
Group 45Q—Electronic Control Units - Software Manager
Group 45R—Electronic Control Units - System Tab Applications
Group 45S—Electronic Control Units - Work Monitor
Group 45U—Electronic Control Units - Work Totals

Section 240—Electrical

Group 05—General Information
Group 50—Diagnostic Tests and Adjustments

Section 245—Electronic Control Units

Group 05—General Information
Group 10A—Operational and Preliminary Checks
Group 10B—Interactive Tests and Calibrations
Group 10C—Programming Electronic Control Units
Group 30A—Display Schematic
Group 50—Diagnostic Test and Adjustments
Group 50A—AutoTrac Guidance Diagnostic Test and Adjustments
Group 50B—AutoTrac Implement Guidance Diagnostic Test and Adjustments
Group 50C—AutoTrac Turn Automation Diagnostic Test and Adjustments
Group 50D—Data Sync Diagnostic Test and Adjustments
Group 50Q—Sharing Diagnostic Test and Adjustments
Group 50P—Software Manager Diagnostic Test and Adjustments
Group VTi—Virtual Terminal Implement Software Addresses (VTi)
Group VTV—Virtual Terminal Vehicle Software Addresses (VTV)

Section 249—Electrical Component Information

Group 05—General Information
Group 40A—Electrical Assemblies

Continued on next page

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.
The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2025
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2023