

# ProGator Utility Vehicle 2020A and 2030A (S.N. 060001-)



## TECHNICAL MANUAL

ProGator Utility Vehicle  
2020A and 2030A  
(S.N. 060001-)

TM117819 12OCT16 (ENGLISH)

Preview Only

John Deere Turf Care  
PRINTED IN U.S.A.




# Introduction

## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-15APR14-1/1

Preview Only

# Contents

## Section 10—Safety

Group 05—Safety

## Section 20—Specifications and Information

Group 05—Specifications  
Group 10—O-Ring Seal Service Recommendations  
Group 15—Fuel  
Group 20—Oils and Lubricants  
Group 25—Coolant  
Group 30—Product Identification

## Section 30—Engine-Gasoline

Group 05—Specifications  
Group 10—Diagnostics  
Group 15—Tests and Adjustments  
Group 20—Repair

## Section 40—Engine-Diesel

Group 05—Specifications  
Group 10—Theory of Operation  
Group 20—Diagnostics  
Group 40—Tests and Adjustments  
Group 50—Repair—3TNV76  
Group 60—Repair—3TNV80F

## Section 50—Electrical

Group 05—General Information  
Group 10—Component Location  
Group 15—Schematics and Harnesses - Gasoline  
Group 20—Schematics and Harnesses - Diesel  
Group 25—Operation and Diagnostics  
Group 30—Tests and Adjustments  
Group 35—Tests and Adjustments EFI Engine  
Group 40—Electronic Controllers  
Group 45—Controller Readings General Information  
Group 50—Operation and Diagnostics - DTC s

## Section 60—Power Train

Group 05—Specifications  
Group 15—Component Location  
Group 20—Theory of Operation  
Group 25—Diagnostics  
Group 30—Tests and Adjustments  
Group 35—Repair

## Section 70—Hydraulics

Group 05—Specifications  
Group 10—Component Location  
Group 15—Schematics and Harnesses

Group 20—Theory of Operation  
Group 25—Diagnostics  
Group 30—Tests and Adjustments  
Group 35—Repair

## Section 80—Steering

Group 05—Specifications  
Group 10—Tools and Materials  
Group 15—Component Location  
Group 20—Theory of Operation  
Group 25—Diagnostics  
Group 30—Tests and Adjustments  
Group 35—Repair

## Section 90—Brakes

Group 05—Specifications  
Group 10—Component Location  
Group 15—Theory of Operation  
Group 20—Diagnostics  
Group 25—Tests and Adjustments  
Group 30—Repair

## Section 100—Miscellaneous

Group 05—Specifications  
Group 10—Repair

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2016  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved.  
A John Deere ILLUSTRATION™ Manual  
Previous Editions  
Copyright © 2012, 2014, 2015

Preview Only

## Section 10 Safety

### Contents

	Page
<b>Group 05—Safety</b>	
Recognize Safety Information .....	10-05-1
Understand Signal Words.....	10-05-1
Replace Safety Signs .....	10-05-1
Handle Fluids Safely—Avoid	
Fires.....	10-05-2
Prepare for Emergencies.....	10-05-2
Prevent Battery Explosions .....	10-05-2
Prevent Acid Burns.....	10-05-3
Wear Protective Clothing.....	10-05-3
Avoid High-Pressure Fluids .....	10-05-4
Avoid Heating Near Pressurized	
Fluid Lines .....	10-05-4
Service Machines Safely .....	10-05-4
Use Proper Tools .....	10-05-5
Park Machine Safely.....	10-05-5
Support Machine Properly .....	10-05-5
Use Proper Lifting Equipment.....	10-05-6
Work in Clean Area .....	10-05-6
Protect Against High Pressure	
Spray .....	10-05-6
Illuminate Work Area Safely .....	10-05-7
Work In Ventilated Area.....	10-05-7
Remove Paint Before Welding or	
Heating .....	10-05-7
Avoid Harmful Asbestos Dust.....	10-05-8
Service Tires Safely.....	10-05-8
Stay Clear of Rotating Drivelines.....	10-05-9
Service Cooling System Safely .....	10-05-9
Dispose of Waste Properly .....	10-05-10
Handle Chemical Products Safely.....	10-05-10
Live With Safety.....	10-05-10